# SPEED CONTROL ZONES

Chronodium
Chronométrage | Géolocalisation

On some sections of the route, **speed is limited** and **monitored by GPS**. The **LEDs on your tracker** show your status in the zone in real time.

1




## ENTERING THE ZONE

All LEDs light up **SOLID ORANGE** and their **BRIGHTNESS INCREASES**.

You are in a speed control zone: respect the indicated **maximum speed**.

2




## EXCEEDING THE SPEED LIMIT

All LEDs **FLASH RED**.

You are exceeding the maximum speed allowed in the zone: **SLOW DOWN** immediately.

3




## LEAVING THE ZONE

The LEDs **TURN OFF**. Only the **PWR** LED stays on.

The tracker returns to **normal operation**.